

STIRLING®

183L UPRIGHT FREEZER

6 Transparent Storage Drawers
Adjustable Thermostat



Features:



183L Storage Capacity
183L gross / 167L net
storage capacity.



Temperature Control
Freezer temperature
is mechanically
adjustable.



Six Storage Drawers
6 Transparent drawers
for organised storage
of frozen goods.



Wire Shelving
With built-in cooling
elements for even cooling
of your frozen goods

Quick Start Guide

Before installing your upright freezer, read all safety instructions in the supplied manual, especially the sections on electrical safety and installation. This Quick Start Guide only covers basic points.

Installation

- Place the freezer on a sturdy, level floor that is strong enough to support the unit when it is fully loaded. Avoid locations that are close to direct sunlight, sources of heat, extreme cold ambient temperatures and areas of high humidity. Make sure the freezer is positioned level and there is a space of at least 12cm at the back and 5cm at the sides for air circulation.
- Before plugging in the freezer, let it stand upright for at least 4 hours to allow the refrigerant gases to settle. After plugging the appliance into a wall outlet, allow the unit to cool down for 2 to 3 hours before placing food inside.

Temperature control

- The temperature control is located at the top of the freezer frame. The MIN mark indicates the warmest setting, MED is the medium setting suitable for normal use, and MAX is the coldest setting.
- The first time you turn the unit on, set the temperature control to the MAX position,
- Then, after 24 hours, adjust the temperature control to the setting that suits your needs.
- To turn the freezer off, turn the temperature control to MIN, which will stop the cooling cycle. Then unplug the unit from the power supply.



Model Number	STR-H183W
Colour	White
Net Capacity	167L
Gross Capacity	183L
Warranty	3 Year in Home Warranty
Version	QSG-V1.0

For more information please visit www.stirlingappliances.com.au or call 1300 886 649