

STIRLING®

30L MICROWAVE OVEN WITH GRILL & CONVECTION

Microwave, Grill & Convection Cooking
10 Power Levels



Features:




10 Power Levels
10 Power levels each for
microwave cooking
(from 10% to 100%)
and convection cooking
(from 110°C to 200°C)



Microwave, Grill & Convection Power
Separate microwave, grill and
convection settings,
plus combination modes,
for all your cooking needs



8 Auto-Cook Options
8 Automatic cooking
options for different food



Convection Function
10 Convection settings
for baking or roasting
at 110°C to 200°C

Control Panel:



DISPLAY WINDOW

Indicates clock, cooking time, etc.

PRESET COOKING SETTINGS

Spaghetti, Reheat, Cake, Pizza, Potato, Popcorn, Beverage, Skewered Meat.

NUMBER PADS

Use to set the time of day, cooking time, temperature, etc.

MICRO+GRILL

Press to select one of two combination cooking settings.

MICRO+CONVECTION

Press to select one of four combination cooking settings.

CONVECTION

Press to program convection cooking.

GRILL

Press to set a grill cooking program.

POWER

Press to select microwave power level.

DEFROST

Press and enter a time to defrost food.

TIMER/CLOCK

Use to set the clock and the minute timer.

WEIGHT DEFROST

Press to defrost food by weight.

START/QUICK START

Press to start a cooking program, or to start the oven quickly at full power.

CANCEL

Press to stop a cooking program, or to clear all previous settings before cooking starts.

Model Number	D90N30ASLR-T4-H
Microwave Output Power	900W
Microwave Input Power	1400W
Convection Power	2200W
Grill Power	1250W
Capacity	30L
Warranty	3 Years



For more information please visit www.stirlingappliances.com.au or call 1300 886 649