


STIRLING[®]

CERAMIC COOKTOP



Features:



Ceramic Cooktop

60cm built in, top mount ceramic cooktop to compliment the STIRLING Electric Oven and Rangehood



4 Cooking Zones

2 large (18cm, 1800W) and 2 smaller (14.5cm, 1200W) cooking zones.



Touch Controls

Digital touch control panel with heating indicator lights and child lock feature.



Easy to Clean Surface

The stylish black ceramic surface is fully sealed and easy to clean.

Quick Start Guide

IMPORTANT: The cooktop must be professionally installed by a licensed electrician. See the full instruction manual for installation instructions and a few preparatory steps before first use.

Using the cooktop


Step 1: Press the Power On/Off button to switch on the cooktop and within 10 seconds, press the select button for the cooking zone you want to use.

Step 2: Press the Up/Down buttons to select the required heat level (from 1 to 9).

Step 3: Cook your food in pots and pans that match the cooking zone diameter.

Step 4: At the end of the cooking time, press the select button for the cooking zone you want to switch off, then press the Down button repeatedly until the number in the heat level display reaches "0". The letter "H" will appear next to the select button, indicating that the cooking zone is still hot.

Step 5: Press the Power On/Off button to switch off the cooktop.



Consult the full instruction manual for comprehensive installation, usage and cleaning instructions and important safety advice.

Model Number	STR-C
Cooktop Cooking Zones	4
Warranty	3 Years In Home
Version	QSGV1.1

