


STIRLING[®]

60cm INDUCTION COOKTOP



Quick Start Guide

IMPORTANT: The cooktop must be professionally installed by a licensed electrician. See the full instruction manual for installation instructions and a few preparatory steps before first use.

Using the cooktop

Step 1: Touch the ON/OFF button to power on the cooktop.

Step 2: Place your food (in a suitable pot or pan) on a cooking zone that matches the pan size.

Step 3: Touch the respective cooking zone selection control and within one minute, select a heat level by touching the (- / +) control.

Step 4: At the end of the cooking time, switch off the cooking zone, either by setting its heat level to "0", or by pressing and holding the respective cooking zone selection button for three seconds. The letter "H" next to a cooking zone selection control indicates that the zone is still hot.

Step 5: Touch the ON/OFF button to switch off the cooktop.

Consult the full instruction manual for comprehensive installation, usage and cleaning instructions and important safety advice.

IMPORTANT!

Only use pots and pans that are suitable for induction cooking. The base of your cookware must be made of material that attracts a magnet.



Model Number	STR-X60IC
Cooktop Cooking Zones	4
Warranty	3 Years In Home
Version	QSGV1.0

