

STIRLING®

GARMENT STEAMER

40 second heat up
60 minutes continuous steam



Features:



Ceramic Coated Steam Plate

For smooth gliding and faster steaming results



Garment Hanger

Built in to help make the steaming process easier



Dual Telescopic Poles

Adjustable dual telescopic poles can be extended for extra height or reduced for compact storage



Large Capacity Water Tank

2.4L transparent removable water tank for 60 minutes of continuous steam

Quick Start:

Read the full instruction manual before use. This Quick Start Guide only gives basic usage instructions.

Once the water tank is filled, follow the below steaming instructions

1. Connect the power cord to a power outlet.
2. Press the power switch. This can be done with your foot lightly pressing on button to save you bending down.



3. The garment steamer has 3 heat settings, low, medium and high. Each setting is indicated by a different indicator light.



Red - High



Green - Medium



Blue - Low

5. Check the care label of the clothes to make sure that the garment can be steamed.
6. If you are unsure, test a different piece of material to make sure that no damage will occur.
7. Do not hold steamer in one place for long periods of time as this may cause damage to your clothes.
8. Hang or attach the clothes to be steamed to the clothes hanger or the pants hanger.
9. Point the steam head in the direction of the clothes and move it slowly up and down the length and breadth of your clothes.
CAUTION! Steam can cause burns, do not point the steam head towards yourself or other people.
10. Gently steam your clothes to assist in removing any wrinkles and refreshing your clothes.

Model Number	GS511
Warranty	1 Year
Version	QSG-V1.1

For more information
please email info@gstrading.com.au
or call 1300 554 124
Between 9am and 5.30pm EST (Mon-Fri)

