

# STIRLING®

## 20L MICROWAVE OVEN WITH GRILL

Multistage Cooking  
5 Power Levels



### Features:



#### 5 Power Levels

Choose from 20, 40, 60, 80 or 100% microwave cooking power in 5 power levels.




#### Microwave & Grill Power

Combines both 800W microwave and 1000W grill cooking power.



#### Multistage Cooking

Set consecutive cooking sequences for multistage cooking.



#### LED Display Screen

Electronic control panel with easy to read LED display screen.

# Quick Start Guide

Read the full instruction manual thoroughly before use. It contains comprehensive usage instructions and important safety advice. This Quick Start Guide only contains a description of the most important control panel buttons.

## Control Panel:



### MENU ACTION SCREEN

Cooking time, power, action indicators and clock time are displayed.

### POWER LEVEL

This button is used to set the microwave cooking power level.

### GRILL/COMBI.

This button is used to set a grill cooking program or two combination cooking programs.

### WEIGHT DEFROST

This button is used to set a weight based defrost program.

### CLOCK/PRESET

This button is used to select a 12-hour or 24-hour clock cycle. It is also used to program the oven for a delayed start time.

### PAUSE/CANCEL

This button is used to cancel a setting or reset the oven before setting a program. It is also used for setting the child lock.

### START/QUICK START (THE DIAL)

Press this dial to start a program and to set the quick start function.

### MENU/TIME/WEIGHT (THE DIAL)

Turn this dial to set the oven clock time, input cooking time, and enter the weight or amount of food. Turning it anticlockwise allows you to select from the auto-cooking menu.

Model Number	D80D20EL-Y4
Microwave Power Output	800W
Grill Power Output	1000W
Capacity	20L
Warranty	3 Years
Version	QSGV2.0

For more information please visit [www.stirlingappliances.com.au](http://www.stirlingappliances.com.au) or call 1300 886 649

