



20L Microwave Oven

5 Power Levels

12 Auto Cooking Settings




Features:



Defrost Setting
For easy defrosting



700W Output Power
700W microwave
cooking power
(1150W input power)



LED Display Screen
Electronic, easy
to read LED
display screen

Quick Start Guide

Read the full instruction manual thoroughly before use. It contains comprehensive usage instructions and important safety advice. This Quick Start Guide only contains a description of the most important control panel buttons.

Control Panel:



DIGITAL DISPLAY

- Power level, cooking time, clock time and action indicators are displayed on the circular screen.
- The food icons around the edge (see page 17 of the manual) represent the auto cooking menus (clockwise from top): popcorn, potatoes, vegetables, beef, fish, chicken, reheat, beverage, rice, pasta, bread, pizza.

FUNCTION DIAL

Turn the dial to:

- Select the Auto Cooking function, then push in the dial (press Enter) and select the weight option by turning the dial.
- Input a cooking time.
- Select a food weight.
- Set the oven clock time.

BUTTONS

Micro Power

Press this button to set the power level.

Preset / Clock / Defrost

Press this button to set the delayed start timer, set the clock or select defrost mode.

Instant Start

Press this button to start a set program, or to start cooking immediately for one minute at 100% power.

Pause/Cancel

Use this button to pause or cancel an operation or program, or to set the child lock.

Model Number VTM20L-01

Microwave Cooking Power 700W

Capacity 20L

Warranty 3 Years

Version QSG-V2.0

For more information please visit www.stirlingappliances.com.au or call 1300 886 649