



STIRLING[®]

Black Edition

TOUCH PANEL RANGEHOOD

90cm BLACK TEMPERED GLASS



Quick Start Guide

IMPORTANT: The rangehood must be professionally installed by a licensed electrician. Make sure to read the full instruction manual with comprehensive installation and operating instructions and important safety advice.

Ducting options

For optimum performance, this touch panel rangehood should be vented to the outside wherever possible, either straight up and through your metal roof, or through your wall, or into your ceiling cavity and then out through your eaves.



Installation

- This touch panel rangehood is designed for installation above a cooking appliance with no more than four hob elements.
- Above an electric cooktop, the rangehood must have a minimum height of 600mm from the underside of the rangehood to the cooktop face.
- Above a gas cooktop, the rangehood must have a minimum height of 650mm from the burner to the underside of the rangehood.
- Please refer to the instruction manual for product dimensions and comprehensive installation instructions.



Operation

- Touch the POWER button to switch on and run the rangehood on low speed; touch the button again to switch the rangehood to standby.
- Touch the PLUS button to increase the speed to medium; touch the button again to run the unit on high speed.
- Touch the MINUS button to decrease the speed to medium; touch the button again to run the unit on low speed.
- Touch the LIGHT button to turn on the rangehood lights; touch the button again to switch off the lights.
- Touch the PLUS and MINUS buttons simultaneously for the rangehood to turn off after five minutes.

| | |
|--------------|-----------------|
| Model Number | STR-PRHTP |
| Warranty | 3 Years In Home |
| Version | QSGV1.0 |

For more information please visit www.stirlingappliances.com.au or call 1300 886 649

