

STIRLING[®]


STAINLESS STEEL DISHWASHER

14 PLACE SETTINGS



Quick Operation Guide

For detailed operating instructions, please read the corresponding content in the manual.




1 Install the dishwasher

Please refer to the “Installation” section on pages 11–14 in the manual. Make sure the water tap is open.



2 Prepare the dishes

Scrape off leftover food and soften burnt food residues with water.



3 Load the baskets

Load the baskets following the dishwasher loading instructions on pages 18–21 in the manual.



4 Fill/check the dispensers

Fill dishwasher detergent into the dispenser compartment and ensure there is liquid rinse aid in the dispenser (this is not necessary if you use a detergent with rinse aid).



5 Select a program and run the dishwasher

Close the door and press the PROGRAM button, then press START/PAUSE to start the program. At the end of the program, wait about 15 minutes before unloading.

For more information please visit www.stirlingappliances.com.au or call 1300 886 649

Model Number	STR-SSDW14
Capacity	14 Place Settings
Warranty	3 Years In Home
Version	QSG-V2.0